
Measure background noise

Use **Procedure 5** to measure background noise.

Procedure 5

- 1 Measure background noise on the loop by using an NE-58B noise-measuring set.
Note: The weighting and termination to be used are 100 kHz flat and 135 ohm, respectively.
- 2 Reject the loop being tested if the measured background noise is not less than 51 dBrn.